

# INSTRUCTIONS

## *Sconce 1 rotating straight arm*



1. Unpack without using any cutter or scissor because of possible scratches. Release the packaging of reflectors without removing it completely.
2. Locate the positioning of the round plate to the wall, respecting the verticality of the lamp.
3. Screw the screws into the thread to remove the plate of the lamp.
4. Fix the round plate to the wall.
5. Screw the hexagonal brass screw without tighten it otherwise painting could be damaged.
6. At this stage, at least 2 operators are necessary. One maintains the lamp, second operator connects electrical wires, then match the holes of the round housing in front of the screws. Then unscrew 2mm of the screws.
7. Remove completely the packaging.
8. Before moving the arms, the screw must not be tightened otherwise painting could be damaged.

